



Aspiratore • Aspirateur • Vacuum cleaner
Laubsauger • Aspirador • Zuigmachine

**RICAMBI
RECHANGES
SPARE PARTS
ERSATZTEILE
RECAMBIOS
ONDERDELEN**



**mod. SIRIO
mod. WINDY
II° Edizione**

N.ord. - N. pieces part. N. - bestell N.	RICAMBI SPARE PARTS	RECHANGES ERSATZTEILE	RECAMBIOS ONDERDELEN	Q	
1 10 1381 33	manico superiore upper handle	guidon superieur Obere griffstange	manillar superior bovenste handgreep	1	
2 10 1382 30	sacco sack	sac Sack	saco zak	1	SIRIO
3 10 1218 90	dado nut	ecrou Mutter	tuerca moer	1	M5 FLANGIATO
4 10 1382 32	sacco sack	sac Sack	saco zak	1	WINDY
5 10 1142 00	rondella washer	rondelle Scheibe	arandela borgring	2	Ø8
6 10 1218 80	vite screw	vis Schraube	tornillo schroef	1	TSTC M5x40
7 10 1210 10	acceleratore accelerator	accélérateur Gashebel	acelerador gas	1	B & S mm1150
7 10 1383 20	acceleratore accelerator	accélérateur Gashebel	acelerador gas	1	TECNAMOTOR mm830
8 10 1381 23	manico inferiore lower handle	guidon inferieur Untere griffstange	manillar inferiore onderste handgreep	1	
9 10 6559 00	vite screw	vis Schraube	tornillo schoef	6	TTSQ M8x40
10 10 2823 07	ruota wheel	roue Rad	rueda wiel	2	Ø 220x45
11 10 1219 00	cuscinetto ball-bearing	roulement Kugellager	cojinete kogellager	8	
12 10 2751 00	rondella washer	rondelle Scheibe	arandela borgring	4	Ø 13x0,8
13 20 1016 00	vite screw	vis Schraube	tornillo schroef	4	
14 10 1384 27	copriruota wheel cover	couvre-roue Radkappe	tapacubos huis	2	Ø 150
15 10 4024 03	dado a galletto wing nut	ecrou a papillon Flügelmutter	tuerca palomilla vleugel moer	2	
16 10 4024 02	rondella washer	rondelle Scheibe	arandela borgring	2	Ø 8,5
17 10 1382 13	tirante tierod	entretoise Zugstange	tirante trekstange	1	
18 10 1381 00	supporto ruote wheel bearing	support des roues Radhalter	soporte rueda houder	DESTRO 1	SIRIO
18 10 1381 02	supporto ruote wheel bearing	support des roues Radhalter	soporte rueda houder	DESTRO 1	WINDY
19 20 1017 00	dado nut	ecrou Mutter	tuerca moer	10	M10x8
20 10 2810 07	ruota wheel	roue Rad	rueda wiel	2	Ø 170x40
21 10 2879 07	copriruota wheel cover	couvre-roue Radkappe	tapacubos huis	2	Ø 90
22 10 1380 10	scocca superiore upper deck	chassis superieure Obere gehäuse	chasis superior bovenste maaidek	1	SIRIO
22 10 1380 12	scocca superiore upper deck	chassis superieure Obere gehäuse	chasis superior bovenste maaidek	1	WINDY
23 10 4024 01	vite screw	vis Schraube	tornillo schroef	2	TTSQ M8x50
24 10 1072 03	leva alzaruote lever	levier Hebel	palanca elevaciòn hendel	2	

N.ord. - N. pieces part. N. - bestell N.	RICAMBI SPARE PARTS	RECHANGES ERSATZTEILE	RECAMBIOS ONDERDELEN		Q	
25 20 1062 00	rondella dentellata washer	rondelle Scheibe	arandela borgring		19	Ø 8E
26 20 1063 00	dado nut	ecrou Mutter	tuerca moer		19	Ø M8
27 10 1071 00	vite screw	vis Schraube	tornillo schroef		2	
28 10 1217 00	vite screw	vis Schraube	tornillo schroef		3	TE M8x35
29 10 1381 53	guarnizione gasket	guarniture Dichtung	guarnición pakking		1	
30 20 1038 00	vite screw	vis Schraube	tornillo schroef		10	TE M8x16
31 30 1021 00	rondella dentellata washer	rondelle Scheibe	arandela borgring		6	Ø 10E
32 10 2725 00	rondella washer	rondelle Scheibe	arandela borgring		2	B13x1,5
33 10 1073 02	supporto bearing	support Halter	soporte houder		1	DESTRO
34 10 1385 00	scocca inferiore lower deck	chassis inferieur Untere gehäuse	chasis inferiore ondeste maaidek		1	SIRIO
34 10 1385 02	scocca inferiore lower deck	chassis inferieur Untere gehäuse	chasis inferiore ondeste maaidek		1	WINDY
35 10 1009 00	chiavetta key	clavette Keil	chaveta spie		1	WOODRUF 4x6,5
36 10 1381 70	supporto bearing	support halter	soporte houder		1	
37 10 1381 83	ventola cooling fan	helice Lufterrad	helice ventilator		1	
38 10 4006 00	vite screw	vis Schraube	tornillo schroef	SINISTRO	1	TE Ø 3/8" UNF x50
39 10 1381 10	supporto ruote wheel bearing	support des roues Radhalter	soporte rueda houder	SINISTRO	1	SIRIO
39 10 1381 12	supporto ruote wheel bearing	support des roues Radhalter	soporte rueda houder		1	WINDY
40 20 2821 00	dado nut	ecrou Mutter	tuerca moer		4	M5 NYLON
41 10 1383 03	coperchio cover	couvercle Deckel	tapa deskel		1	
42 10 5522 00	vite screw	vis Schraube	tornillo schroef		4	TC M5x12
43 10 1384 80	distanziale spacer	entretoise Abstandstuck	distanciador afstandsring		1	Ø 11/22/10H
44 10 1073 01	supporto bearing	support Halter	soporte houder		1	SINISTRO
45 10 1384 03	Spinotto di sicurezza Safety plug	fiche de sécurité Sicherheit Stecker	espina de seguridad pin		1	
46 10 1383 63	interruttore di sicurezza Safety switch	Interrupteur de sécurité Sicherheit Schalter	Interruptor de seguridad schakelaar		1	
47 10 1126 00	vite screw	vis Schraube	tornillo schroef		2	TGS M4 x 35
48 10 2874 00	dado nut	ecrou Mutter	tuerca moer		2	M4 NYLON
49 10 7827 00	rondella elastica washer	rondelle Unterlegscheibe	arandela borgring		1	Ø 11/40



