


mod. ERMA 460 T4L - ERMA 460 T4L/K


N.ord. - N. pieces part. N. - Bestell N.	RICAMBI SPARE PARTS	RECHANGES ERSATZTEILE	RECAMBIOS ONDERDELEN	SOBRESSALENTES CZĘŚCI ZAMIENNE	CSEREALKATRÉSZEK NÁHRADNÉ SÚRÁSTKY	Q	
1 10 1220 12	scocca deck	chassis Gehäuse	chasis maaideck	chassi obudowa	váz karoséria	1	ERMA 460 T4L
2 10 1218 40	assale posteriore rear axle	assieu arrière Hintere Achsengruppe	eje trasero achteras	eixo de tras os tylnia	hátso tengely zadná os	1	
3 10 1480 93	supporto assale support	support Halter	soporte houder	suporte uchwyt	tartó drziak	2	
4 20 1357 20	vite screw	vis Schraube	tornillo schroef	parafuso šruba	csavar skrutka	5	TCTC 2F Ø5x16
5 10 1212 02	manico superiore Upper handle	guidon superieur Obere Griffstange	manillar superior bovenste handgreep	guiador superior górný uchwyt	felső markolat horná rúčka	1	
6 10 1482 23	tappo plug	bouchon Kappe	tapón dop	tampão zaslepka	dugó uzáver	2	
7 10 1462 33	rondella washer	rondelle Scheibe	arandela borgring	anilha podkladka	alátét podložka	2	
8 10 1216 63	flangia flange	bride Flansch	brida flens	flange flangia	karima obrúda	1	
9 10 1216 73	flangia flange	bride Flansch	brida flens	flange flangia	karima obrúda	1	
10 10 1219 70	leva lever	levier Hebel	palanca hendel	alavanca dźwignia	elemő páka	1	
11 20 1072 03	guaina sheathing	gaine Hülle	forro hulsel	protecção da manete osłona	tok puzdro	1	
12 10 1462 60	perno pin	pivot Zapfen	pivote pin	perno koleczek	csap kolik	1	